

EGE322 Iot System Project Project Presentation

Development of Smart Home Automation

Armando ()

Sanjeev (221325c)



Table of contents

01

Introduction

02

Overview of Project

03

Our prototype

04

Hardware overview

05

Software overview

06

Outcome, Demo of
project

07

Problems, Encountered &
Solution

08

Reference & Conclusion

01

Introduction



Theme

Preventive Healthcare Measures for Malnutrition

Problem

Despite the increasing awareness of the importance of nutrition, modern lifestyles often lead to imbalanced diets, contributing to malnutrition and related health issues. Traditional methods of diet tracking and management are time-consuming and often lack accuracy, hindering proactive healthcare.

Objective

The primary objective of the smart cabinet is to enhance preventive healthcare measures for malnutrition by providing comprehensive visibility into an individual's dietary habits and health data. This system aims to support better diagnosis and prognosis by offering doctors detailed and accurate information about a patient's daily health and lifestyle. Additionally, it seeks to promote healthy eating habits through personalised recommendations and automated inventory management.

Integration with Healthcare Providers

The smart cabinet's ability to gather and send detailed nutrient consumption reports and health data to doctors bridges the gap between daily habits and medical advice. This integration supports preventive healthcare by enabling doctors to offer more precise recommendations based on accurate, real-time data.



Sub-Objective

- Automate Inventory Management
 - AI-powered Image Recognition: Automatically identifies and catalogs food items.
 - Live Feed and User Interface: Provides a real-time view of the cabinet's contents through an app or web dashboard.
- Impact: Streamlines grocery management, reduces food waste and ensures the family always has fresh and nutritious options.
- Quality of Life (QOL) Changes
 - Promote Healthy Eating: Personalized recipe suggestions and tailored recommendations help the family make healthier food choices.
 - Track and Analyze Eating Habits: Provides insights into dietary patterns, helping users make informed decisions about their diet.
- Impact: Enhances the overall quality of life by making it easier to maintain a healthy diet, ultimately leading to better health outcomes.




02

Overview of Project



System Block Diagram



Project Description

The IoT-enabled smart cabinet is a novel solution designed to address the challenges of maintaining a healthy diet. By combining AI, IoT, and sensor technology, the cabinet provides real-time insights into food consumption, nutritional intake, and overall health. It offers personalized recommendations, automates inventory management, and integrates with healthcare providers to facilitate preventive healthcare.

Project Objective

Enhance preventive healthcare measures for malnutrition through comprehensive dietary monitoring and analysis.

Provide personalized nutrition recommendations to promote healthy eating habits.

Automate inventory management to reduce food waste and ensure access to fresh, nutritious food.

Integrate with healthcare providers to enable better diagnosis and treatment.

Features

1. Habit Tracker

- ESP32 Cam(core): Captures images of food items placed in the cabinet, enabling AI-powered image recognition to identify and catalogue these items.
- Weight Sensor(core): Tracks the amount of food consumed, providing data on eating habits and portion control.

Role: By tracking what and how much food is consumed, the habit tracker helps identify nutritional patterns and deficiencies. This data is crucial for providing personalized health recommendations and alerts.

Features

2. Nutrition Facts and Craving Detector

1. Craving Detector: Analyzes the lack of vitamins in the blood, alerting users to potential nutrient deficiencies.
2. Nutrient Deficit Alert(**core**): Sends notifications when the diet lacks essential nutrients.

Role: These features ensure that the family maintains a balanced diet, addressing any deficiencies promptly to prevent malnutrition and related health issues.

Features

3. Health Data Gatherer

1. Sensors (Temperature, Humidity, Heart Rate)(**core**): Collect vital health data from individuals.
2. Logistics: Tracks and logs the use of items from the cabinet, maintaining an accurate inventory.


Role: Gathering comprehensive health data allows for better understanding and monitoring of each family member's health, aiding doctors in making more informed diagnoses and recommendations.

Extra Features

1. Auto Locks : Restricts access to pest and other things allowing the food inside to have a longer shelf life
2. Phone Access and Knock Knock Feature: Allows users to see inside the cabinet via touch or phone, enhancing convenience and preserving the internal environment.

Role: These features ensure that the family follows healthy eating habits and schedules, reducing the risk of overeating or consuming unhealthy snacks.

Our System Uniqueness




03

Our prototype



First Proof of concept circuitry



Prototype 1 (Cabinet)

Used a shoebox:

- cut out a hole to mount the esp32 cam
- Initially used UV light strips
- The Light strips are powered by a 12V power supply


Decided against this because:

- space constraint
- visually unappealing



Initial (Cabinet)

Created a mount for the esp32 cam and place it there to take image



- Build the box
- Connected everything to check if the concept works



Improved (Cabinet)

- We realise insufficient light was hitting the esp32 cam we added a led ceiling ring like to the top.
- We mounted the Esp32 cam using hot glue gun after finding the optimal spot for the fov to capture the whole box
- We cleaned up the wiring and did a bit of rewiring and cable management

Final (Cabinet)

- We added black foam to reduce the amount of light bouncing into the camera causing it the image to be over exposed
- Created a base for the box so that the components can be hid under and also to allow the load cell to work better


Internal View



External View



smartwatch



3d model

This shows the UI of the watch at it initial stages

3D model made to fit all the components inside to make it a wearable.

04

Hardware Overview



Smart watch Hardware overview



Pulse sensor

The pulse sensor monitors the heart-rate and biofeedback of the body measuring the change in volume of a blood vessel that occur when the heart pumps blood using an optical sensor and green LED.

The HR data is sent to the watch to be displayed in real time and sent which is also sent to the server



Ncir sensor

NCIR is a single-point infrared temperature sensor that detects temperature by measuring the infrared radiation emitted with a temperature measurement range of -70°C to $+380^{\circ}\text{C}$.

The HR data is sent to the watch to be displayed in real time and sent which is also sent to the server



Oled

The organic light-emitting diode (OLED) display is a mono color, 0.96-inch display with 128×64 pixels

It is used to display all the health data (Heart rate, body temperature) and other health reports and alerts

Smart watch Hardware overview




Potentiometer

The potentiometer is used to control the smart watch by allowing it to turn the page and showing hovering over the item it wants to select



Button

The button allows the watch to wake and sleep and also works with the potentiometer to select functions in the watch to display such as the heart rate and the health report



Legends:

- = SCL
- = SDA
- = VCC
- = GND
- = Analog input
- = digital input

Hardware overview (cabinet)



Esp-32 cam

ESP32-CAM is a low-cost ESP32-based development board with onboard camera, small in size

It is used to take image of the inside of the cabinet to send to the server to run it through its yolo ML model to know the items in the cabinet



Relay

The relay is used to turn on the Electrochromic glass in the cabinet so that when the touch sensor is activated it will turn on and let the user look into the cabinet



Led strip

The Led strip is turn on when activated to increase the brightness in the cabinet so that it would be easier for the esp 32 cam to take photos of the items inside the cabinet

Hardware overview (cabinet)



Servo motor

The servo motor will be used to open the door , when prompt it will open or close the locking mechanism allowing the door to be open.



Button

Toggles the servo motor to open and close the door of the cabinet



Electrochromic glass

Electrochromic glass changes its light transmittance only when triggered by an electrical signal

It turns transparent when activated by the touch sensor

Hardware overview (cabinet)



Capacitive touch

(aluminium foil)


It was self made by us by adding a large piece of aluminium foil where when it is touched it sends a signal to the esp32 to turn the electrochromic glass transparent



Load cell / HX711

The load cell measures mechanical force, mainly the weight of objects. Connected to HX711 a precision 24-bit analog-to-digital converter (ADC).

It is used to track the amount of weight of the items in the box to track the amount of food ate by the user



Note:
We could always use [aluminium foil](#) to acts as capacitive touch for now (in speaker notes)

Legends:

- = Sck
- = PWM
- = VCC
- = GND
- = digital output
- = digital input

05

Software Overview



Smart health watch



Libraries(OLED)

```

1 # MicroPython SSD1306 OLED driver, I2C and SPI interfaces
2
3 from micropython import const
4 import framebuffer
5
6
7 # register definitions
8 SET_CONTRAST = const(0x81)
9 SET_ENTIRE_ON = const(0x44)
10 SET_NORM_INV = const(0x46)
11 SET_DISP = const(0x4E)
12 SET_MEM_ADDR = const(0x20)
13 SET_COL_ADDR = const(0x21)
14 SET_PAGE_ADDR = const(0x22)
15 SET_DISP_START_LINE = const(0x40)
16 SET_SEG_REMAP = const(0x40)
17 SET_MUX_RATIO = const(0x68)
18 SET_COM_OUT_DIR = const(0xC0)
19 SET_DISP_OFFSET = const(0x03)
20 SET_COM_PIN_CFG = const(0x0A)
21 SET_DISP_CLK_DIV = const(0x05)
22 SET_PRECHARGE = const(0x09)
23 SET_VCOM_DESEL = const(0x0B)
24 SET_CHARGE_PUMP = const(0x8D)
25
26 # Subclassing framebuffer provides support for graphics primitives
27 # http://docs.micropython.org/en/latest/pyboard/library/framebuf.html
28 class SSD1306(framebuf.FrameBuffer):
29     def __init__(self, width, height, external_vcc):
30         self.width = width
31         self.height = height
32         self.external_vcc = external_vcc
33         self.pages = self.height // 8
34         self.buffer = bytearray(self.pages * self.width)
35         super().__init__(self.buffer, self.width, self.height, framebuf.MONO_VLSB)
36         self.init_display()
37
38     def init_display(self):
39         for cmd in (
40             SET_DISP | 0x00, # off
41             # address setting
42             SET_MEM_ADDR,
43             0x00, # horizontal
44             # resolution and layout
45             SET_DISP_START_LINE | 0x00,
46             SET_SEG_REMAP | 0x01, # column addr 127 mapped to SEG0
47             SET_MUX_RATIO,
48             self.height - 1,
49             SET_COM_OUT_DIR | 0x08, # scan from COM[N] to COM0
50             SET_DISP_OFFSET,
51             0x00,
52             SET_COM_PIN_CFG,
53             0x02 if self.width > 2 * self.height else 0x12,
54             # timing and driving scheme
55             SET_DISP_CLK_DIV,
56             0x00,
57             SET_PRECHARGE,
58             0x22 if self.external_vcc else 0xF1,
59             SET_VCOM_DESEL,
60             0x30, # 0.83*Vcc
61             # display
62             SET_CONTRAST,

```

```

63             # display
64             SET_CONTRAST,
65             0x7F, # max brightness
66             SET_ENTIRE_ON, # output follows RAM contents
67             SET_NORM_INV, # not inverted
68             # charge pump
69             SET_CHARGE_PUMP,
70             0x00 if self.external_vcc else 0x14,
71             SET_DISP | 0x01,
72         ):
73             self.write_cmd(cmd)
74         self.fill(0)
75         self.show()
76
77     def poweroff(self):
78         self.write_cmd(SET_DISP | 0x00)
79
80     def poweron(self):
81         self.write_cmd(SET_DISP | 0x01)
82
83     def contrast(self, contrast):
84         self.write_cmd(SET_CONTRAST)
85         self.write_cmd(contrast)
86
87     def invert(self, invert):
88         self.write_cmd(SET_NORM_INV | (invert & 1))
89
90     def show(self):
91         x0 = 0
92         x1 = self.width - 1
93         if self.width == 64:
94             # displays with width of 64 pixels are shifted by 32
95             x0 += 32
96             x1 += 32
97         self.write_cmd(SET_COL_ADDR)
98         self.write_cmd(x0)
99         self.write_cmd(x1)
100         self.write_cmd(SET_PAGE_ADDR)
101         self.write_cmd(0)
102         self.write_cmd(self.pages - 1)
103         self.write_data(self.buffer)
104
105 class SSD1306_I2C(SSD1306):
106     def __init__(self, width, height, i2c, addr=0x3C, external_vcc=False):
107         self.i2c = i2c
108         self.addr = addr
109         self.temp = bytearray(2)
110         self.write_list = [b'w', None] # C=0, D/CR=0
111         super().__init__(width, height, external_vcc)
112
113     def write_cmd(self, cmd):
114         self.temp[0] = 0x80 # C=0
115         self.temp[1] = cmd
116         self.i2c.writeto(self.addr, self.temp)
117
118     def write_data(self, buf):
119         self.write_list[1] = buf
120         self.i2c.writeto(self.addr, self.write_list)
121
122 class SSD1306_SPI(SSD1306):
123     def __init__(self, width, height, spi, dc, res, cs, external_vcc=False):
124         self.rate = 10 * 1024 * 1024
125         dc.init(dc.OUT, value=0)
126         res.init(res.OUT, value=0)
127         cs.init(cs.OUT, value=1)
128         self.spi = spi
129         self.dc = dc
130         self.res = res
131         self.cs = cs
132         import time
133
134         self.res(1)
135         time.sleep_ms(1)
136         self.res(0)
137         time.sleep_ms(10)
138         self.res(1)
139         super().__init__(width, height, external_vcc)
140
141     def write_cmd(self, cmd):
142         self.spi.init(baudrate=self.rate, polarity=0, phase=0)
143         self.cs(1)
144         self.dc(0)
145         self.cs(0)

```

```

146         self.spi.write(bytearray([cmd]))
147         self.cs(1)
148
149     def write_data(self, buf):
150         self.spi.init(baudrate=self.rate, polarity=0, phase=0)
151         self.cs(1)
152         self.dc(1)
153         self.cs(0)
154         self.spi.write(buf)
155         self.cs(1)
156

```

A module that I imported so i can run my oled display from the main file

Libraries(HX711)

```
1 from time import sleep, time
2 from machine import Pin
3 from micropython import const
4
5
6 class HX711Exception(Exception):
7     pass
8
9
10 class InvalidMode(HX711Exception):
11     pass
12
13
14 class DeviceIsNotReady(HX711Exception):
15     pass
16
17
18 class HX711(object):
19     """
20     Micropython driver for Avia Semiconductor's HX711
21     24-Bit Analog-to-Digital Converter
22     """
23     CHANNEL_A_128 = const(1)
24     CHANNEL_A_64 = const(3)
25     CHANNEL_B_32 = const(2)
26
27     DATA_BITS = const(24)
28     MAX_VALUE = const(0xffffffff)
29     MIN_VALUE = const(0x80000000)
30     READY_TIMEOUT_SEC = const(5)
31     SLEEP_DELAY_USEC = const(80)
32
33     def __init__(self, d_out: int, pd_sck: int, channel: int = CHANNEL_A_128):
34         self.d_out_pin = Pin(d_out, Pin.IN)
35         self.pd_sck_pin = Pin(pd_sck, Pin.OUT, value=0)
36         self.channel = channel
37
38     def __repr__(self):
39         return "HX711 on channel %s, gain=%s" % self.channel
40
41     def _convert_from_twos_complement(self, value: int) -> int:
42         """
43         Converts a given integer from the two's complement format.
44         """
45         if value & (1 << (self.DATA_BITS - 1)):
46             value -= 1 << self.DATA_BITS
47         return value
48
49     def _set_channel(self):
50         """
51         Input and gain selection is controlled by the
52         number of the input PD_SCK pulses
53         3 pulses for Channel A with gain 64
54         2 pulses for Channel B with gain 32
55         1 pulse for Channel A with gain 128
56         """
57         for i in range(self._channel):
58             self.pd_sck_pin.value(1)
59             self.pd_sck_pin.value(0)
60
61     def _wait(self):
62         """
63         If the HX711 is not ready within READY_TIMEOUT_SEC
64         the DeviceIsNotReady exception will be thrown.
65         """
66         t0 = time()
67         while not self.is_ready():
68             if time() - t0 > self.READY_TIMEOUT_SEC:
69                 raise DeviceIsNotReady()
70
71     @property
72     def channel(self) -> tuple:
73         """
74         Get current input channel in a form
75         of a tuple (Channel, Gain)
76         """
77         if self._channel == self.CHANNEL_A_128:
78             return 'A', 128
79         if self._channel == self.CHANNEL_A_64:
80             return 'A', 64
81         if self._channel == self.CHANNEL_B_32:
82             return 'B', 32
```

```
83 @channel.setter
84 def channel(self, value):
85     """
86     Set input channel
87     HX711.CHANNEL_A_128 - Channel A with gain 128
88     HX711.CHANNEL_A_64 - Channel A with gain 64
89     HX711.CHANNEL_B_32 - Channel B with gain 32
90     """
91     if value not in (self.CHANNEL_A_128, self.CHANNEL_A_64, self.CHANNEL_B_32):
92         raise InvalidMode('Gain should be one of HX711.CHANNEL_A_128, HX711.CHANNEL_A_64, HX711.CHANNEL_B_32')
93     else:
94         self._channel = value
95
96     if not self.is_ready():
97         self._wait()
98
99     for i in range(self.DATA_BITS):
100         self.pd_sck_pin.value(1)
101         self.pd_sck_pin.value(0)
102
103     self._set_channel()
104
105 def is_ready(self) -> bool:
106     """
107     When output data is not ready for retrieval,
108     digital output pin DOUT is high.
109     """
110     return self.d_out_pin.value() == 0
111
112 def power_off(self):
113     """
114     When PD_SCK pin changes from low to high
115     and stays at high for longer than 60 us ,
116     HX711 enters power down mode.
117     """
118     self.pd_sck_pin.value(0)
119     self.pd_sck_pin.value(1)
120     sleep_us(self.SLEEP_DELAY_USEC)
121
122 def power_on(self):
123     """
124     When PD_SCK returns to low, HX711 will reset
125     and enter normal operation mode.
126     """
127     self.pd_sck_pin.value(0)
128     self.channel = self._channel
129
130 def read(self, raw=False):
131     """
132     Read current value for current channel with current gain.
133     If raw is True, the HX711 output will not be converted
134     from two's complement format.
135     """
136     if not self.is_ready():
137         self._wait()
138
139     raw_data = 0
140     for i in range(self.DATA_BITS):
141         self.pd_sck_pin.value(1)
142         self.pd_sck_pin.value(0)
143         raw_data = raw_data << 1 | self.d_out_pin.value()
144     self._set_channel()
145
146     if raw:
147         return raw_data
148     else:
149         return self._convert_from_twos_complement(raw_data)
```

A module that I imported so i can access the data being sent from the load cell to the HX711 to the main file

Libraries(NCIR/MLX90614)

```
27 import ustruct
28
29 class SensorBase:
30
31     def read16(self, register):
32         data = self.i2c.readfrom_mem(self.address, register, 2)
33         return ustruct.unpack('<H', data)[0]
34
35     def read_temp(self, register):
36         temp = self.read16(register)
37         # Apply measurement resolution (0.02 degrees per LSB)
38         temp *= 0.02
39         # Kelvin to Celsius
40         temp -= 273.15
41         return temp
42
43     def read_ambient_temp(self):
44         return self.read_temp(self._REGISTER_TA)
45
46     def read_object_temp(self):
47         return self.read_temp(self._REGISTER_TOB31)
48
49     def read_object2_temp(self):
50         if self.dual_zone:
51             return self.read_temp(self._REGISTER_TOB32)
52         else:
53             raise RuntimeError("Device only has one thermopile")
54
55     @property
56     def ambient_temp(self):
57         return self.read_ambient_temp()
58
59     @property
60     def object_temp(self):
61         return self.read_object_temp()
62
63     @property
64     def object2_temp(self):
65         return self.read_object2_temp()
66
67 class MLX90614(SensorBase):
68
69     _REGISTER_TA = 0x06
70     _REGISTER_TOB31 = 0x07
71     _REGISTER_TOB32 = 0x08
72
73     def __init__(self, i2c, address=0x5a):
74         self.i2c = i2c
75         self.address = address
76         _config1 = i2c.readfrom_mem(address, 0x25, 2)
77         _dz = ustruct.unpack('<H', _config1)[0] & (1<<6)
78         self.dual_zone = True if _dz else False
79
80 class MLX90615(SensorBase):
81
82     _REGISTER_TA = 0x26
83     _REGISTER_TOB31 = 0x27
84
85     def __init__(self, i2c, address=0x5b):
86         self.i2c = i2c
87         self.address = address
88         self.dual_zone = False
```

A module that I imported so i can access the data being sent by the NCIR sensor from the main file

TEMP(Temperature)

```
1 from machine import Pin, PWM, I2C, Timer, ADC
2 from time import sleep
3 import ssd1306
4 import HR
5 import TEMP
6 import framebuffer
7
8
9
10
11
12 temp_data = [
13     (0x00000011, 0x00000000),
14     (0x00000100, 0x10011000),
15     (0x00000100, 0x10000000),
16     (0x00000100, 0x10011100),
17     (0x00000100, 0x10000000),
18     (0x00000100, 0x10010000),
19     (0x00000100, 0x10000000),
20     (0x00000100, 0x10011100),
21     (0x00000100, 0x10000000),
22     (0x00000100, 0x10011000),
23     (0x00000100, 0x10000000),
24     (0x00010000, 0x01000000),
25     (0x00010000, 0x00010000),
26     (0x00100000, 0x00001000),
27     (0x00100000, 0x00001000),
28     (0x00100000, 0x00001000),
29     (0x00100000, 0x00001000),
30     (0x00010000, 0x00010000),
31     (0x00001000, 0x01000000),
32     (0x00000111, 0x10000000),
33
34 ]
35
36
37 def TEMP(display, button_pin, temp):
38     display.fill(0)
39     buffer = bytearray(temp_data)
40     fb = framebuffer.FrameBuffer(buffer, 16, 20, framebuffer.MONO_HLSB)
41     display.blit(fb, 40, 17) # Adjust coordinates as needed for centering
42     temperature = temp.read_object_temp()
43     display.text(" {:.2f}C".format(temperature), 52, 47, 1)
44     display.show()
45     sleep(1)
```

- **Initialization:**

- a. Imports libraries.
- b. Sets up pins for button, display communication (likely I2C), etc. (not shown).

- **Heart Rate:**

- a. HR module likely handles pulse sensor reading, peak detection, and BPM calculation (details not shown here).

- **Temperature:**

- a. TEMP module likely reads the temperature sensor.
- b. TEMP function displays a custom temperature icon on the OLED using framebuffer.
- c. It then reads the temperature and displays it with two decimal places.

Display Updates:

- The code likely calls functions from HR and TEMP to retrieve heart rate and temperature values.
- It refreshes the display with the heart rate (potentially using a separate function) and temperature using the TEMP function shown.

Libraries(Pulse sensor)

```
1 from machine import Pin, ADC
2 from time import sleep, ticks_ms, ticks_diff
3 import time
4
5 class PulseSensor:
6     def __init__(self, adc_pin=34, led_pin=0, low_threshold=180, high_threshold=200, smoothing_window_size=5, bpm_estimation_interval=15):
7         self.adc = ADC(Pin(adc_pin))
8         self.adc.atten(ADC.ATTN_120DB)
9         self.led = Pin(led_pin, Pin.OUT)
10
11         # Threshold values
12         self.low_threshold = low_threshold
13         self.high_threshold = high_threshold
14
15         # Peak detection variables
16         self.previous_signal = 0
17         self.peak_detected = False
18         self.last_peak_time = 0
19
20         # BPM calculation variables
21         self.peak_times = []
22         self.bpm_estimation_interval = bpm_estimation_interval
23         self.peak_count = 0
24         self.start_time = time.ticks_ms()
25
26         # Kalman filter variables
27         self.Q = 0.1 # Process noise covariance
28         self.R = 0.1 # Measurement noise covariance
29         self.K = 0.0 # Value
30         self.P = 1.0 # Estimation error covariance
31         self.K = 0.0 # Kalman gain
32
33         # Smoothing variables
34         self.smoothing_window_size = smoothing_window_size
35         self.signal_window = []
36
37         # Peak count variables for 30-second interval BPM calculation
38         self.peak_count = 0
39         self.start_time = time.ticks_ms()
40
41         # Method switch
42         self.use_filter_method = False
43
44     def kalman_filter(self, value):
45         self.P = self.P + self.Q
46         self.K = self.P / (self.P + self.R)
47         self.x = self.x + self.K * (value - self.x)
48         self.P = (1 - self.K) * self.P
49         return self.x
50
51     def smooth_signal(self, signal):
52         self.signal_window.append(signal)
53         if len(self.signal_window) > self.smoothing_window_size:
54             self.signal_window.pop(0)
55         return sum(self.signal_window) / len(self.signal_window)
56
57     def read_sensor(self):
58         return self.adc.read()
59
60     def detect_peaks_and_calculate_bpm(self):
61         # Read the PulseSensor's value
62         current_signal = self.read_sensor()
63         smoothed_signal = self.smooth_signal(current_signal) # Smooth the signal
64         filtered_signal = self.kalman_filter(smoothed_signal) # Apply Kalman filter
65
66         estimated_bpm = 0
67
68         # Check if the signal is within the desired range
69         if self.low_threshold < filtered_signal < self.high_threshold:
70             if filtered_signal > self.previous_signal:
71                 self.peak_detected = True
72             elif filtered_signal < self.previous_signal and self.peak_detected:
73                 # A peak is detected
74                 self.peak_detected = False
75                 self.peak_count += 1
76                 self.led.on() # Turn on LED for a heartbeat
77                 print("Heartbeat detected")
78             else:
79                 self.led.off() # Turn off LED if no heartbeat is detected
80
81         else:
82             self.peak_detected = False
83             self.led.off() # Turn off LED if signal is out of range
84
85         # Update previous signal
86         self.previous_signal = filtered_signal
87         print(filtered_signal)
88
89         # Delay for stability
90         time.sleep_ms(50)
91
92         # Calculate BPM after 15 seconds
93         bpm = self.peak_count * 6 # Calculate BPM based on peaks counted
94         print(f"BPM: {bpm}")
95
96         return bpm
```

```
96
97     self.led.on() # Turn on LED for a heartbeat
98     print(f"Heartbeat detected, estimated BPM: {estimated_bpm:.2f}")
99
100     self.peak_detected = False
101
102     else:
103         self.led.off() # Turn off LED if no heartbeat is detected
104
105     else:
106         self.peak_detected = False
107         self.led.off() # Turn off LED if signal is out of range
108
109     # Update previous signal
110     self.previous_signal = filtered_signal
111
112     return estimated_bpm
113
114 # Inside PulseSensor class
115
116 def calculate_bpm_over_15sec(self):
117     self.start_time = time.ticks_ms()
118     self.peak_count = 0
119     while time.ticks_diff(time.ticks_ms(), self.start_time) < 15000:
120         current_signal = self.read_sensor() # Read the PulseSensor's value
121         smoothed_signal = self.smooth_signal(current_signal) # Smooth the signal
122         filtered_signal = self.kalman_filter(smoothed_signal) # Apply Kalman filter
123
124         # Check if the signal is within the desired range
125         if self.low_threshold < filtered_signal < self.high_threshold:
126             if filtered_signal > self.previous_signal:
127                 self.peak_detected = True
128             elif filtered_signal < self.previous_signal and self.peak_detected:
129                 # A peak is detected
130                 self.peak_detected = False
131                 self.peak_count += 1
132                 self.led.on() # Turn on LED for a heartbeat
133                 print("Heartbeat detected")
134             else:
135                 self.led.off() # Turn off LED if no heartbeat is detected
136
137         else:
138             self.peak_detected = False
139             self.led.off() # Turn off LED if signal is out of range
140
141         # Update previous signal
142         self.previous_signal = filtered_signal
143         print(filtered_signal)
144
145         # Delay for stability
146         time.sleep_ms(50)
147
148         # Calculate BPM after 15 seconds
149         bpm = self.peak_count * 6 # Calculate BPM based on peaks counted
150         print(f"BPM: {bpm}")
151
152     return bpm
```

This is a Custom made library, made by us to get the data from the pulse sensor and access it from the main file

HR (Heart rate)

```
1 from machine import Pin, I2C, ADC
2 import ssd1306
3 import time
4 from pulse_sensor import PulseSensor
5
6 button_pin = Pin(25, Pin.IN, Pin.PULL_UP)
7
8
9 adc = ADC(Pin(34))
10 adc atten(ADC.ATTN_11DB) # Set the attenuation to read a wider range of voltages
11
12 MAX_HISTORY = 200
13 TOTAL_BEATS = 30
14 HEART = [
15     [0, 0, 0, 0, 0, 0, 0, 0, 0],
16     [0, 1, 1, 0, 0, 0, 1, 1, 0],
17     [1, 1, 1, 1, 0, 1, 1, 1, 1],
18     [1, 1, 1, 1, 1, 1, 1, 1, 1],
19     [1, 1, 1, 1, 1, 1, 1, 1, 1],
20     [0, 1, 1, 1, 1, 1, 1, 1, 0],
21     [0, 0, 1, 1, 1, 1, 1, 0, 0],
22     [0, 0, 0, 1, 1, 1, 0, 0, 0],
23     [0, 0, 0, 0, 1, 0, 0, 0, 0],
24 ]
25 last_y = 0
26
27 def refresh(bpm, beat, v, minima, maxima, display):
28     global last_y
29
30     display.vline(0, 0, 64, 0)
31     display.scroll(-1, 0) # Scroll left 1 pixel
32
33     if maxima - minima > 0 and 1800 <= v <= 1900:
34         # Draw beat line with larger scaling for visibility.
35         y = 80 - int(100 * (v - minima) / (maxima - minima)) # Adjust the scaling factor for better visibility
36         display.line(125, last_y, 125, y, 1)
37         last_y = y
38
39     # Clear top text area.
40     display.fill_rect(0, 0, 128, 16, 0) # Clear the top text area
41
42     if bpm:
43         display.text("%d bpm" % bpm, 12, 0)
44
45     # Draw heart if beating.
46     if beat:
47         for y, row in enumerate(HEART):
48             for x, c in enumerate(row):
49                 display.pixel(x, y, c)
50
51     display.show()
```

1. Pin Configuration:

- button_pin: Input pin for the button with pull-up resistor (**active when not pressed**).
- adc: Instance for analog-to-digital conversion (**reading sensor voltage**).
- adc.atten(ADC.ATTN_11DB): Adjusts voltage reading range for better sensor compatibility.

2. Constants:

- MAX_HISTORY: Maximum number of recent sensor readings to store (e.g., 200).
- TOTAL_BEATS: Maximum number of recent heartbeats to track (e.g., 30).

3. Heartbeat Visualization (HEART):

- Predefined pattern representing a heartbeat displayed on the screen.

4. refresh Function (Display Update):

- Clears the display area and scrolls content left for animation.
- **Heartbeat Line (if detected):**
 - Calculates a scaled position based on voltage for visualization.
 - Draws a line representing the heartbeat.
- **Heart Rate Text:** Displays calculated heart rate if available.
- **Heartbeat Animation (if detected):**
 - Iterates through the HEART pattern to draw pixels and create the animation.
- Updates the display with all drawn elements.

HR (Heart rate)

```
53 def HR(display,button_pin):
54     history = []
55     beats = []
56     beat = False
57     bpm = None
58     last_valid_bpm = 60
59
60     Hr_sensor = PulseSensor()
61
62     while True:
63         button_state = button_pin.value()
64         if button_state == 1:
65             bpm = Hr_sensor.detect_peaks_and_calculate_bpm()
66             v = Hr_sensor.read_sensor()
67             raw_data = adc.read()
68             history.append(raw_data)
69
70             # Get the tail, up to MAX_HISTORY length
71             history = history[-MAX_HISTORY:]
72
73             minima, maxima = 1700, 2000
74
75             if bpm > 0:
76                 beat = True
77                 beats.append(time.time())
78                 # Truncate beats queue to max
79                 beats = beats[-TOTAL_BEATS:]
80                 last_valid_bpm = bpm # Update last valid BPM
81             else:
82                 beat = False
83                 bpm = last_valid_bpm # Use last valid BPM if current BPM is zero
84
85             refresh(bpm, beat, v, minima, maxima, display)
86
87     elif button_state == 0:
88         break
89
```

The code is designed to measure and display heart rate using a pulse sensor.

Here's how it works:

1. **Data Collection:** It continuously reads data from the pulse sensor and stores recent readings.
2. **Heartbeat Detection:** It analyzes the sensor data to identify peaks, which represent heartbeats.
3. **Heart Rate Calculation:** It calculates the heart rate based on the time between detected heartbeats.
4. **Display Update:** It displays the calculated heart rate and other relevant information on a connected display.
5. **Button Control:** The code waits for a button press to start or stop the heart rate measurement.

Page_1 (Homepage design)

This are the designs for the heart, thermometer, and health report

```
1 from machine import Pin, I2C
2 import ssd1306
3 import framebuffer
4 from time import sleep
5
6
7
8
9 health = [
10     0b00000111, 0b11100000,
11     0b00000111, 0b11100000,
12     0b00000111, 0b11100000,
13     0b00000111, 0b11100000,
14     0b00000111, 0b11100000,
15     0b11111111, 0b11111111,
16     0b11111111, 0b11111111,
17     0b11111111, 0b11111111,
18     0b11111111, 0b11111111,
19     0b00000111, 0b11100000,
20     0b00000111, 0b11100000,
21     0b00000111, 0b11100000,
22     0b00000111, 0b11100000,
23     0b00000111, 0b11100000,
24     0b00000000, 0b00000000,
25     0b00000000, 0b00000000,
26
27 ]
```

```
29 heart_data = [
30     0b00000000, 0b00000000,
31     0b00000100, 0b00010000,
32     0b00001110, 0b00111000,
33     0b00011111, 0b11111100,
34     0b00111111, 0b11111110,
35     0b00111111, 0b11111110,
36     0b00111111, 0b11111100,
37     0b00011111, 0b11111000,
38     0b00001111, 0b11110000,
39     0b00000111, 0b11100000,
40     0b00000011, 0b11000000,
41     0b00000001, 0b10000000,
42     0b00000000, 0b00000000,
43     0b00000000, 0b00000000,
44     0b00000000, 0b00000000,
45     0b00000000, 0b00000000,
46 ]
```

```
47 temp_data = [
48     0b00000011, 0b00000000,
49     0b00000100, 0b10011000,
50     0b00000100, 0b10000000,
51     0b00000100, 0b10011100,
52     0b00000100, 0b10000000,
53     0b00000100, 0b10010000,
54     0b00000100, 0b10000000,
55     0b00000100, 0b10011100,
56     0b00000100, 0b10000000,
57     0b00000100, 0b10011000,
58     0b00000100, 0b10000000,
59     0b00010000, 0b01000000,
60     0b00010000, 0b00100000,
61     0b00100000, 0b00010000,
62     0b00100000, 0b00010000,
63     0b00100000, 0b00010000,
64     0b00100000, 0b00010000,
65     0b00010000, 0b00100000,
66     0b00010000, 0b01000000,
67     0b00001111, 0b10000000,
68
69
70 ]
```

Page_1 (Homepage design)

```
73 def select(rows,column,display):
74     grid_width = 2
75     grid_height = 2
76     cell_size = 30
77     cell_spacing = 1
78     selected_row = rows    # Initially select the top-left cell
79     selected_col = column
80
81     # Calculate starting position
82     start_x = (display.width // 2) - ((grid_width * cell_size + (grid_width - 1) * cell_spacing) // 2)
83     start_y = (display.height // 2) - ((grid_height * cell_size + (grid_height - 1) * cell_spacing) // 2)
84
85     while True:
86         display.fill(0) # Clear the screen
87
88         # Draw the Grid
89         for row in range(grid_height):
90             for col in range(grid_width):
91                 x = start_x + col * (cell_size + cell_spacing)
92                 y = start_y + row * (cell_size + cell_spacing)
93                 if row == selected_row and col == selected_col:
94                     display.fill_rect(x, y, cell_size, cell_size, 1) # Filled for selected cell
95                 else:
96                     display.rect(x, y, cell_size, cell_size, 1) # Outline for other cells
97
98         HR = bytearray(heart_data)
99         TEMP = bytearray(temp_data)
100         Health = bytearray(health)
101         fbHR = framebuf.FrameBuffer(HR, 16, 16, framebuf.MONO_HLSB)
102         fbTEMP = framebuf.FrameBuffer(TEMP, 16, 20, framebuf.MONO_HLSB)
103         fbHealth = framebuf.FrameBuffer(Health, 16, 16, framebuf.MONO_HLSB)
104         display.blit(fbHR, 42,12)
105         display.blit(fbTEMP, 75,8)
106         display.blit(fbHealth, 42,41)
107         display.show()
108         break
```

Functionality: Presents a grid layout on the OLED display and allows selection of a cell using button presses (button handling likely not shown).

Grid Parameters:

- Number of rows and columns (rows, column - likely received as arguments)
- Cell size (cell_size)
- Spacing between cells (cell_spacing)

Display Update Loop:

1. Clears the screen.
2. Draws the grid:
 - Iterates through rows and columns.
 - Calculates the position of each cell based on screen size and grid parameters.
 - Draws a filled rectangle for the currently selected cell.
 - Otherwise, draws an outline for other cells.
3. Displays health icons (assuming heart_data, temp_data, and health are predefined byte arrays representing icon data):
 - Converts each bytearray to a framebuf.FrameBuffer object for efficient display.
 - "Blitz" (draws) each icon buffer onto the OLED display at specific coordinates.
4. Shows the updated display.

Main code (Initialisation/setup)

```
13 # Potentiometer setup
14 pot_pin = ADC(Pin(33))
15 pot_pin.atten(ADC.ATTN_11DB)
16 pot_pin.width(ADC.WIDTH_12BIT)
17
18 # Button setup
19 button_pin = Pin(25, Pin.IN, Pin.PULL_UP)
20
21 # OLED setup
22 i2c = I2C(sda=Pin(21), scl=Pin(22), freq=100000)
23 display = ssd1306.SSD1306_I2C(128, 64, i2c)
24 temp_sensor = mlx.MLX90614(i2c)
25
26 # Pulse Sensor setup
27 Hr_sensor = PulseSensor()
28
29 temp_sensor = mlx.MLX90614(i2c)
```

Potentiometer:

- Creates an ADC object (**pot_pin**) for reading analog values from pin 33.
- Sets the voltage attenuation to 11dB (**ADC.ATTN_11DB**) for better resolution at lower voltages.
- Sets the analog-to-digital conversion width to 12 bits (**ADC.WIDTH_12BIT**) for higher precision.

Button:

- Creates a Pin object (**button_pin**) for reading button state from pin 25.
- Sets the pin mode to input (**Pin.IN**) and enables a pull-up resistor (**Pin.PULL_UP**) to ensure a high default state.

OLED:

- Creates an I2C object (**i2c**) for communicating with the OLED display.
- Creates an SSD1306 object (**display**) to control the OLED display with a resolution of 128x64 pixels.
- Creates an MLX90614 object (**temp_sensor**) for reading temperature using the MLX90614 sensor.

Pulse Sensor:

- Creates a PulseSensor object (**Hr_sensor**) for measuring heart rate from the pulse sensor (implementation details might vary depending on the library).

Main code (WifiConect module)

```
31 # WLAN setup
32 sta_if = network.WLAN(network.STA_IF)
33 sta_if.active(True)
34 WIFI_SSID = "MFDAB Wifi"
35 WIFI_PASS = "SANJEEV1303"
36
37 # Socket Configuration
38 SERVER_IP = "192.168.18.2" # Server IP
39 SERVER_PORT = 5001 # Server Port
40 s = None # Socket object
41
42 def connect_wifi():
43     sta_if.connect(WIFI_SSID, WIFI_PASS)
44     while not sta_if.isconnected():
45         sleep(1)
46     print('Connected to Wi-Fi with IP:', sta_if.ifconfig()[0])
```

This function establishes a Wi-Fi connection to the specified network.

1. WLAN setup would activate the Wi-Fi interface (`sta_if`) and set the SSID and password for connection.
2. Socket Configuration initializes variables for the server IP address, server port, and the socket object (`s`) which starts as `None` (not yet connected).
3. **Connects to the Wi-Fi network:** Uses the `sta_if.connect()` method to initiate the connection using the provided SSID and password.
4. **Waits for connection:** Continuously checks if the connection is established using `sta_if.isconnected()`. If not, it waits for 1 second before checking again.
5. **Prints connection status:** Once connected, it prints the device's IP address to the console for confirmation.

Main code (Server Communications)

```
49 ▾ def server_comms(s):
50 ▾     while True:
51 ▾         try:
52 ▾             data = s.recv(1024) # <8 = ok
53 ▾             if data == b"bpm":
54 ▾                 bpm_value = Hr_sensor.calculate_bpm_over_15sec()
55 ▾                 temperature = temp_sensor.read_object_temp() # Correct way to
56 ▾                 s.send(f"{bpm_value:.2f},bpm".encode("utf-8"))
57 ▾                 s.send(f"{temperature:.2f},temp".encode("utf-8"))
58 ▾         except OSError as e:
59 ▾             print("Socket error:", e)
60 ▾             # Handle the error as needed, e.g., reconnect or continue
```

This function handles communication with the server.

1. **Continuous loop:** Runs indefinitely to maintain a connection.
2. **Receives data:** Attempts to receive data from the server using `s.recv(1024)`.
3. **Checks for "bpm" command:** If the received data is "bpm", it calculates the heart rate and temperature.
4. **Sends data to server:** Sends the calculated heart rate and temperature values to the server in a specific format.
5. **Error handling:** If a socket error occurs, it prints an error message and likely handles the error (e.g., reconnecting).

Main code (Main loop)

```
62 def main_loop():
63     while True:
64         pot_value = pot_pin.read()
65         button_state = button_pin.value()
66
67         if pot_value == 0:
68             page_1.select(3, 3)
69
70         elif pot_value <= 1024:
71             page_1.select(0, 0)
72             if button_state == 0:
73                 sleep(0.5)
74                 HR.HR(display, button_pin)
75                 page_1.select(3, 3)
76                 sleep(1)
77
78         elif pot_value <= 2048:
79             page_1.select(1, 0)
80
81         elif pot_value <= 3072:
82             page_1.select(0, 1)
83             if button_state == 0:
84                 sleep(0.2)
85             while True:
86                 button_state = button_pin.value()
87                 if button_state == 1:
88                     sleep(0.5)
89                     TEMP.TEMP(display, button_pin, temp)
90                     continue
91                 elif button_state == 0:
92                     break
93             page_1.select(3, 3)
94             sleep(1)
95
96         elif pot_value <= 4096:
97             page_1.select(1, 1)
98
```

This function is the main program loop that controls the device's behavior.

1. **Continuous loop:** Runs indefinitely to keep the program running.
2. **Reads potentiometer and button values:** Reads the current values from the potentiometer and button.
3. **Handles potentiometer value ranges:** Based on the potentiometer value, it selects what information should be displayed on the OLED.
4. **Button handling:** If the button is pressed, it performs specific actions like starting heart rate measurement or displaying temperature.

Main code (Main Program)

```
99 # Start main loop and server communications
100 connect_wifi()
101 s = socket.socket(socket.AF_INET, socket.SOCK_STREAM)
102 s.connect((SERVER_IP, SERVER_PORT))
103 print('Connected to server')
104 s.send(b"new~wch")
105
106 _thread.start_new_thread(server_comms, (s,))
107 main_loop()
```


- Establishes Wi-Fi connection.
- Creates a TCP socket for server communication.
- Connects to the specified server.
- Sends an initial message to the server.
- Starts a new thread to handle server communication.
- Initiates the main program loop.

Cabinet



How to install Lemivara's firmware for esp32 cam (option 1)

1. Download the whole code





2. Unzip the folder



How to install Lemivara's firmware for esp32 cam (option 1)


3. Go to "Run" -> "Configure Interpreter.."

4. Select "Micropython (ESP32)" (green) and follow below




How to install Lemivara's firmware for esp32 cam (option 1)

5. Find the  icon and follow below




6. Find the file under "firmware"



Note:
Some people could use the firmware with the "_cmake_". However, I only was successful in using the "camera_no_ble"

7. Press install



To check if your firmware is working check it with your serial monitor

- any will do: Arduino IDE (assuming you have download the esp32 board driver before), Thonny or even putty (if you can configure)

How to install Lemivara's firmware for esp32 cam (option 2)

```
esptool.py --chip esp32 --port /dev/ttyUSB0 erase_flash  
esptool.py --chip esp32 --port /dev/ttyUSB0 write_flash -z 0x1000 micropython_camera_feeeb5ea3_esp32_id
```


- Note: if this code run on your command prompt and gives you an error, you could always remove the "--port /dev/ttyUSB0" or "--port COM7"
- To check if your firmware is working check it with your serial monitor
 - any will do: Arduino IDE(assuming you have download the esp32 board driver before) , Thonny or even putty (if you can configure)

Context

Server always prompt the cabinet to do a task. The response to this could be:


- **Gather and send sensor information**
 - E.g. Request for ESP32 Cam to take pictures

Sequence of events:



- **Actuate an actuator**
 - E.g. Turns off the LED strips

Sequence of events:




All devices here will follow the convention 1 of sending info from ESP32 to server

Sending info using sockets

Convention 1


- Before sending message:
 - Send the size of the message to be sent
- After acknowledgement for size declaration:
 - Send the message to receiver



- Only seen by Client to server (more details in assignment)


Convention 2

- Send the information from the transmitter to receiver
 - In the cabinet's case usually information are 4 characters long



- Only using the server to ESP client (more details in assignment)

Control Flow:



ESP32 CAM on Start

Initialise socket

```
client_socket = socket.socket()  
client_socket.connect((SERVER_IP, SERVER_PORT))
```

Makes a socket object with the address family of AF_INET and of SOCK_STREAM socket type. Then connect to server

```
while True:  
    msg = client_socket.recv(35)  
    print(msg)  
    if b"id" in msg:  
        break
```

Wait for server to recognise that a client has been connected.
- Over here the client waits for the request for id from server

```
id_name = b"new~" + name.encode('utf-8')  
client_socket.send(id_name)  
print("confirm")  
while b"start" not in client_socket.recv(32):  
    continue
```

Sends the id it wants to be called on in the server side.

- Then wait until the server finishes registering the client
- More can be seen in the assignment

Initialise Wifi

```
sta_if = network.WLAN(network.STA_IF)  
sta_if.active(True)
```

Make WLAN network interface that connects to Wifi's Access points and activate the station interface

```
all_wifi = sta_if.scan()
```

Scans for all available access points

```
for wifi in all_wifi:  
    if WIFI_SSID in wifi[0]:
```

Check if from all the access points they have the same ssid as the one we want to connect

```
sta_if.connect(WIFI_SSID, WIFI_PASS)
```

Connect to the wifi's access point of the SSID we specified

Repeat until we are connected


```
while sta_if.isconnected() != True:
```

- Ensure that we will always connect to wifi if the access point is available

ESP32 Wroom on Start

Start

Initialise the pins according to the diagram



```
# sensor and actuator initialisers
weight_sens = HX711(dout=26, pd_sck=27) # PD_SCK = digital out, Dout = digital in
weight_sens.set_scale(10)
weight_sens.tare()
motor = PWM(Pin(14), freq = 50)
btn = Pin(23, Pin.IN) # external pullup, does work
led_pin = Pin(15, Pin.OUT)
led_strip = neopixel.NeoPixel(led_pin, NO_OF_LED)
glass = Pin(17, Pin.OUT)
touch_pin = TouchPad(Pin(4))
```

Initialise the weight sensor readings

- On start, weigh the cabinet when its empty(128g) and when it has a predetermined weight(481g)
 - It reads the load cell for 50 times and give you the average of the weight
- Assuming the weight and load cell readings are linearly proportional
 - Find the gradient and y-intercept

```
m, c = cali_weight(weight_sens, EMPTY_WEIGHT, CALI_WEIGHT)
```

```
if start_cali == "e":
    init_weight = float(weight_sens.read_average(times = 50))
if start_cali == "c":
    const_weight = float(weight_sens.read_average(times = 50))
```

```
m = (CALI_WEIGHT - EMPTY_WEIGHT)/(const_weight - init_weight)
c = init_weight
```

Similarly to ESP32 CAM, initialise for socket and wifi

Button is pressed

Button is pressed

```
btn.irq(trigger=Pin.IRQ_FALLING, handler=handle_interrupt)
```

- I set it as falling so even if you hold the button there will only be counted as 1
- Also, for Ux it feels better to press and immediately get to see results
 - Instead of lifting your finger from the button

For debounce and resistance against noise coupling

```
def handle_interrupt(pin):  
    ...  
    FYI:  
    - The button requires a capacitor because it is very inconsistent without it  
    - As in it will affect the chromatic glass's gpio  
    ...  
    global door_open, send_info, lastDebounce  
    current = time.ticks_ms()  
    if time.ticks_diff(current, lastDebounce) <= 1500:  
        print("Exiting interrupt")  
        return  
    time.sleep_ms(50) # Short delay to filter out noise  
    lastDebounce = current  
    if btn.value() == 0: # Check if the button is still pressed. for debounce  
        door_open = not door_open  
        send_info = True  
        print(f"button {door_open}")
```

Acts as flags for the conditions in the main code

```
if send_info == True and door_open:
```

```
elif send_info and not door_open:
```

Check weight

*reads 50 times of the load cell
and finds the average

Send weight

Convention
1

Saves weight
(before opening)

Unlocks
cabinet door

```
weight = float(weight_sens.read_average(times = 50)) * m / 10
print(f"weight {weight}")
weight = str(weight).encode("utf-8")
client_socket.send(b"size-{}".format(len(weight))) # size decl
while send_msg == False:
    continue
```

```
req_server = client_socket.recv(35)
```

```
if b"send" in req_server:
    send_msg = True
```

```
weight = f"{state}-".encode("utf-8") + weight # declare what s
client_socket.send(weight)
send_msg = False
```

```
elif b"bfr" in data[:4]:
    print(f"before {data_str}")
    before_weight = data_str
```

```
motor.duty(80)# open
```

Locks the cabinet door

Open the LED strip's lights

Sets all LEDs to (r = 255,g = 255,b = 255)

Check weight

*reads 50 times of the load cell and finds the average

Send weight

Sends request for ESP32 CAM for picture

```
motor.duty(30) # close
```

```
led_rgb_setter(led_strip , NO_OF_LED , 255 , 255 ,255)
```

```
weight = float(weight_sens.read_average(times = 50)) * m / 10  
print(f"weight {weight}")  
weight = str(weight).encode("utf-8")  
client_socket.send(b"size-{}".format(len(weight))) # size decl  
while send_msg == False:  
    continue
```

```
req_server = client_socket.recv(35)
```

```
if b"send" in req_server:  
    send_msg = True
```

```
weight = f"{state}-".encode("utf-8") + weight # declare what s  
client_socket.send(weight)  
send_msg = False
```

```
if b"aft" in data[:4]:  
    print(f"after {data_str}")
```

```
send_img_req()
```

Convention
1

This is done so that nothing can be changed before I read and take the picture

Sends
request for
ESP32 CAM
for picture

Convention 2

Finds all the clients known id called
img

```
def send_img_req():  
    for keys in client_to_send.keys():  
        print(f"stuff {client_to_send[keys][1]}")  
        if b"img" == client_to_send[keys][1]:  
            print(f"sending req to {client_to_send[keys][0]}")  
            client_to_send[keys][0].send(b"img") # Send image request to client  
    return "sent" # Return sent  
  
req_server = client_socket.recv(35)  
print("requested")  
if req_server == b"img":
```

Saves weight
(after
opening)

```
if b"aft" in data[:4]:  
    print(f"after {data_str}")  
    curr_weight = data_str
```

Initialise
camera

Takes a picture and
de-initialise camera

```
try:  
    camera.init(0, format=camera.JPEG)  
    pic_in_bytes = camera.capture()  
    print(len(pic_in_bytes))  
    size = len(pic_in_bytes)  
    return pic_in_bytes , size  
except Exception as e:  
    print("error")  
finally:  
    camera.deinit() # de initialise a
```

- I used finally in try and except because in any case it will always deinit the camera

Send
picture

```
client_socket.send(b"size-{}".format(len(msg)))  
while b"send" not in client_socket.recv(32): #  
    continue  
client_socket.send(msg) # sends message  
return True
```

Saves and
decode
picture

We decided to overwrite our
pictures after every receive

```
img = Image.open(io.BytesIO(data))
```

```
pic_name = '1.png'
```

```
pic_name = "/Users/Sanjeev/Desktop/IOT sys project/static/images/" + pic_name
```

```
img.save(pic_name)
```

Send request
to close LED
strip's lights

Finds all the clients known id called
img

```
for keys in client_to_send.keys():  
    print(f"stuff {client_to_send[keys][1]}")  
    if b"cab" == client_to_send[keys][1]:  
        print(f"sending req to {client_to_send[keys][0]}")  
        client_to_send[keys][0].send(b"lof") # Send LED off request to client  
return "sent cab" # Return sent cab
```

Close LED
strip's lights

```
req_server = client_socket.recv(35)  
print(f"requested {req_server}")  
if req_server == b"lof": # request to close lights  
    led_rgb_setter(led_strip , NO_OF_LED , 0 , 0 ,0)
```

Sets all LEDs to (r = 255,g = 255,b =
255)

Convention 2

Predict items in picture

Create Yolo object

For items that are predicted as x item for 60% or more confidence are outputted. The image size allowed is only 640. The images will then be annotated and saved in a runs/detect/predict_

- Where _ is the amount of folders of predict there are
- e.g. under runs/detect/
 - predict
 - predict2
 - predict3

Get Each item's boxes object.
Find its classification and put it into a list from the boxes object

I set it as:

- 0: nutella
- 1: pepsi
- 2: pringles

As yolo's convention for labelling is numbers

Show predicted items and picture in web server and save data

Make all items into the Item object

Add the items predicted into the "Item" table

Save changes

```
model = YOLO(model_path) # Load the YOLO model
predict_results = model.predict(image, imgsz = 640 , conf = 0.6 , save = True)
```

```
for r in predict_results:
    boxes = r.boxes # Boxes object for bbox outputs
    predicted_food = boxes.cls.tolist()
```

```
if predicted_food[i] == 0:
    all_items["Nutella"] += 1
elif predicted_food[i] == 1:
    all_items["Pepsi"] += 1
elif predicted_food[i] == 2:
    all_items["Pringles"] += 1
```

```
with app.app_context():
    Item.query.delete()
    for i in item:
        new_item = Item(name= i, quantity = item[i])
        db.session.add(new_item)
        db.session.commit()
```

Show predicted
items and picture in
web server and save
data

To show image on the webpage

```
<div class="img-container">
  <img id="img" width="160" height="160">
  
</div>
```

Update the items in the html using jinja

```
@app.route("/cabinet")
def cabinet():
    items = Item.query.all() # Query all items
    return render_template('cabinet.html', items=items)
```

Query the whole Item table and put it
into jinja's arguments

Loops through all the
items and find its item
name and quantity

```
<ul id="cabinet-items-list">
  {% for item in items %}
  <li>{{ item.name }}: {{ item.quantity }}</li>
  {% endfor %}
</ul>
```


Dashboard/Website



IOT SYSTEM Project

Welcome to Health Plus

Users

Doctors

Email

User Name

Password

[Forgot password?](#)

Sign in

LOGIN PAGE

IOT SYSTEM Project

Welcome to Health Plus

Users

Doctors

Dr_ID

Dr_name

Dr_IC

TwoFA

[Forgot password?](#)

Sign in

Data Sheet

Time	Heart Rate (HR)	Temperature (Temp)
11 Jul 08:49:58	44.00	23.11
11 Jul 08:50:28	44.00	23.11
11 Jul 08:51:03	28.00	23.11
11 Jul 08:51:33	52.00	23.11
11 Jul 08:52:08	48.00	23.11
11 Jul 08:52:38	48.00	23.11
11 Jul 08:53:13	48.00	23.11
11 Jul 08:53:48	56.00	23.11
11 Jul 09:04:11	88.00	23.11
11 Jul 09:04:41	60.00	23.11
11 Jul 09:05:11	152.00	23.11
11 Jul 11:21:01	8.00	23.11

Home page

Welcome back SIR



[Habit Tracker](#)



[Health Report](#)



[Cabinet](#)



[Health Monitoring](#)

This is the main page where it links to the the Health monitor, Cabinet, Health Report and Habit tracker to get more info on each category

Habit Tracker

The habit tracker analyses and track the nutrients you have eaten based on the data from the cabinet and the smart watch

Health Report

The health report helps you view your health report from the hospital and allows you to send health comments to the doctor

Cabinet





The Cabinet allows you to view the items in the cabinet via your phone such that it would allow easier logistics as you do not need to remember the items in the cabinet

Health monitoring

The Health monitoring helps track the smart watch users health data like heart rate, blood glucose, blood oxygen meter, and body temperature in real time and also within a range of a week





Health Monitoring page

Tracks the real time health data and updates the round progress bar around the icons to show a sense of healthiness which is based on a range for a healthy person



Health Monitoring data

Displayed health data from over the past 7 days (week) so that it is easier to detect any abnormalities in the health data.




Cabinet

Displayed a the latest photo of inside the cabinet from the last time the cabinet was open

<

Cabinet Items



Cabinet Items:

Nutella: 0

Pepsi: 1

Pringles: 0

Lorem Ipsum has been the industry's standard dummy text ever since the 1500s, when an unknown printer took a galley of type and scrambled it to make a type specimen book.

Health Report

helps you view your health report from the hospital and allows you to send health comments to the doctor

<

Health Report



view Report in PDF



Share with you doctor



Doctor's Note

Health Report viewer

This page shows your health report stats all your medical report details and the comments and suggestions from the doctor to improve your daily lifestyle habits

Health Report

Blood Test Results

Total Cholesterol	1
Triglyceride	2
HDL-C	1
LDL	2
Chol/HDL	1
Bilirubin	2
ALT	1
AST	2
ALP	1
Golbulin	2
Protein	1
Albumin	21
Creatinine	1
Potassium	2
eGFR	3
HbA1c	4

Doctor's Advice

Cardiovascular: Listen to your body's whispers, not its shouts. Daily habits like regular sleep, healthy meals, and movement are the foundation of health. Don't wait for illness to strike. Let's build a personalized plan together. Together, we can cultivate a vibrant you!

Glucose: Listen to your body's whispers, not its shouts. Daily habits like regular sleep, healthy meals, and movement are the foundation of health. Don't wait for illness to strike. Let's build a personalized plan together. Together, we can cultivate a vibrant you!

Diet: Listen to your body's whispers, not its shouts. Daily habits like regular sleep, healthy meals, and movement are the foundation of health. Don't wait for illness to strike. Let's build a personalized plan together. Together, we can cultivate a vibrant you!

Exercise: Listen to your body's whispers, not its shouts. Daily habits like regular sleep, healthy meals, and movement are the foundation of health. Don't wait for illness to strike. Let's build a personalized plan together. Together, we can cultivate a vibrant you!

Mental: Listen to your body's whispers, not its shouts. Daily habits like regular sleep, healthy meals, and movement are the foundation of health. Don't wait for illness to strike. Let's build a personalized plan together. Together, we can cultivate a vibrant you!

Respiratory: Listen to your body's whispers, not its shouts. Daily habits like regular sleep, healthy meals, and movement are the foundation of health. Don't wait for illness to strike. Let's build a personalized plan together. Together, we can cultivate a vibrant you!

Digestive: Listen to your body's whispers, not its shouts. Daily habits like regular sleep, healthy meals, and movement are the foundation of health. Don't wait for illness to strike. Let's build a personalized plan together. Together, we can cultivate a vibrant you!

Bone Health: Listen to your body's whispers, not its shouts. Daily habits like regular sleep, healthy meals, and movement are the foundation of health. Don't wait for illness to strike. Let's build a personalized plan together. Together, we can cultivate a vibrant you!

Immunizations: Listen to your body's whispers, not its shouts. Daily habits like regular sleep, healthy meals, and movement are the foundation of health. Don't wait for illness to strike. Let's build a personalized plan together. Together, we can cultivate a vibrant you!

Share with doctor

Allows the user to comment on their health so that the doctor can read it and get a better understanding on the patient and diagnose them better

Share with your doctor

Medications:

This includes all prescription and over-the-counter medications that the patient is taking, including vitamins and herbal supplements....

Immunizations

This includes a record of all the vaccinations the patient has received....

Social history

This includes information about the patient's living situation, marital status, occupation, and stress levels...

Sleep

How many hours of sleep do you typically get per night? Do you have trouble falling asleep or staying asleep?

Exercise

How often do you exercise? What type of exercise do you do? For how long?

Stress levels

Do you feel stressed on a daily basis? How do you manage stress?

Alcohol and tobacco use

Do you drink alcohol? If so, how much and how often? Do you smoke?

Screen time

How much time do you spend looking at screens each day (TV, computer, phone)?

[Back](#)[General Advice](#)

Doctor's note

Allows the users to view comments and suggestions from the doctor to improve your daily lifestyle habits

Share with your doctor

Medications:

This includes all prescription and over-the-counter medications that the patient is taking, including vitamins and herbal supplements....

Immunizations

This includes a record of all the vaccinations the patient has received....

Social history

This includes information about the patient's living situation, marital status, occupation, and stress levels...

Sleep

How many hours of sleep do you typically get per night? Do you have trouble falling asleep or staying asleep?

Exercise

How often do you exercise? What type of exercise do you do? For how long?

Stress levels

Do you feel stressed on a daily basis? How do you manage stress?

Alcohol and tobacco use

Do you drink alcohol? If so, how much and how often? Do you smoke?

Screen time

How much time do you spend looking at screens each day (TV, computer, phone)?

[Back](#)[General Advice](#)

Health Tracker data

Displays the macro nutrients that the user has intake and loss based on the cabinet and smart watch.

Habit Tracker

Energy



9 mg

Fat



1000 mg

sugar



2.4 mcg

Fiber



1000 mg

Protiens



1000 mg

salt



2.4 mcg

Weight:

Show More: ☐

Health Tracker data

Displayed health data from over the past 7 days (week) so that it is easier to detect any abnormalities in the health data.




07

Problem & Solution




Problem & solution (Hardware)



Problem	Solution
ESP32 Cam rarely is able to take good quality photos for the ML model to predict	<ul style="list-style-type: none">- Don't use the camera for more than 1 hour- If the camera starts to give error photos press the "RST" or unplug and plug

RST

Error photos



Good photo




Problem & solution (Hardware)

Problem	Solution
The connectors keeps coming loose and loosing connection for the electrochromic glass	We decided to wire wrap the connection cables
Pins of the esp32 causes noise coupling and causes abnormal data readings for the button	We added capacitors to the button's pin to the ground to reduce the noise and change the location as far from other pins

Problem & solution (Hardware)

Problem	Solution
Did not know the voltage needed to supply the electrochromic glass. (The manufacturer did not give any datasheet)	Soldered two pieces of wires to be able to measure the voltage in parallel. Then Connect these wires to the jumper and connector



Problem & solution (Hardware)

Problem	Solution
Electrochromic glass requires high voltage (around 20 - 34V) and low current	Used the USB connector(that has a transformer) and connect it via a relay to supply or leave the electrochromic glass open
Lack of brightness for the camera	We experimented with led strips, UV light strips and in the end we used a ceiling light with around 30k lumens
The box was to bright after light addition and the white colour was reflecting the light causing the image to be over exposed	We added black foam to the sides to reduce the amount of light bouncing.

Problem & solution (Software)

Problem	Solution
There was no readily available library for the pulse sensor	We had to create a custom library to run the pulse sensor
The Pulse sensor data being received was to noisy and unreadable	We added a Kalman filter to reduce the amount of noise
Having 2 threads that receive sockets. This makes the order of where the message gets received is ambiguous	Put all the receive into 1 socket receive

Problem & solution (Software)



Problem	Solution
The button was unreliable due to bouncing	Added a debouncing code and extra delay due to the electrochromic glass
The frame buffer will never stay constant because there are many users sending info to the server	<p>The ESP32 clients usually declare their size of message before sending and if any messages are received before then, they will use the largest frame buffer</p> <ul style="list-style-type: none">- Hence, the frame buffer will always be bigger than any message
It is hard to identify and call the whole remote address to send info to a esp32 client	Associate the given id(from the esp client on start) with its remote address on the server. So it is easier for the programmer to send info to a client.

Problem & solution (Software)


Problem	Solution
For the CV training, the pictures were taken from many sources. Hence, relabeling and splitting of images is required	I made a script to rename all the labels of nutella(as it had a different label to the other dataset I have) and split the images into training, testing and validation
The model was not able to predict properly predict	Added some extra pictures taken from the esp32 cam as training,testing and validation dataset

Problem & solution (Software)

Problem	Solution
Serial monitor of Thonny was not working For Esp32 Cam	<u>Set the following parameters</u> for configuration.ini



Configuration.ini



Problem & solution (Website & server)

Problem	Solution
Adafruit is very restrictive in the amount of features able to add and not enough feature	We decided to create our own website and Server to communicate between the esp32's and website using knowledge of html, css, js & python

08

Reference & Conclusion



References

- <https://youtu.be/8A4dqoGL62E?si=o7QooOgwWbd1o6Av>
- <https://youtu.be/436VDF-rk4w?si=HLJeLFKR8mP-bj8Y>
- <https://youtu.be/Kg-sxVmCt5Q?si=pJ8aw7vPxOXJIFL6>
- <https://youtu.be/xZF6zWLz-vY?si=vn6EXkiPK49Wyo5H>
- <https://youtu.be/TDgM8eMTplw?si=Jgo6hKibeRnFMYET>
- <https://lastminuteengineers.com/pulse-sensor-arduino-tutorial/>
- <https://randomnerdtutorials.com/esp32-touch-pins-arduino-ide/>

Troubleshooting:

- <https://github.com/thonny/thonny/issues/2845>
- <https://blog.csdn.net/zhusongziye/article/details/128176230>
- <https://github.com/thonny/thonny/issues/2282>

Documentation ,libraries and firmware

- <https://github.com/lemariva/micropython-camera-driver>
- <https://docs.python.org/3/library/socket.html>
- <https://docs.ultralytics.com/models/yolov9/#usage-examples>
- <https://docs.micropython.org/en/latest/index.html>

Dataset:

- https://drive.google.com/drive/folders/1Y50k5xA9a6E_1hBGsiXxJK3iCsmsFKud?usp=sharing

